

遥控扇	起动键		记忆功能	风类				定时	摆头			彩灯可选择(L版)	脚位数
	开关键	风速键		常	自	睡	按键	累加-A 不累加-N	数目	按键	可调角度		
HS8202BN8/L		●	●	●	●		1	1, 2, 4, 8-N	2	2		0, 1	20, 22
HS8202BN8K/L	●		●	●	●		1	1, 2, 4, 8-N	2	2		0, 1	20, 22
HS8203BN8/L		●	●	●	●		1	1, 2, 4, 8-N	1	1		0, 1	18, 20
HS8203BN8K/L	●		●	●	●		1	1, 2, 4, 8-N	1	1		0, 1	18, 20
HS8204BA4/L		●	●	●	●	●	1	0.5, 1, 2, 4-A	2	1		0, 1	20, 22
HS8204BA4K/L	●		●	●	●	●	1	0.5, 1, 2, 4-A	2	1		0, 1	20, 22
HS8204BN3/L		●	●	●	●	●	1	1, 2, 4-N	2	1		0, 1	20, 22
HS8204BN3K/L	●		●	●	●	●	1	1, 2, 4-N	2	1		0, 1	20, 22
HS8206BA4/L		●	●	●	●	●	1	0.5, 1, 2, 4-A	1	1		0, 1	18, 20
HS8206BA4K/L	●		●	●	●	●	1	0.5, 1, 2, 4-A	1	1		0, 1	18, 20
HS8206BN3/L		●	●	●	●	●	1	1, 2, 4-N	1	1		0, 1	18, 20
HS8206BN3K/L	●		●	●	●	●	1	1, 2, 4-N	1	1		0, 1	18, 20
HS8207BA4S/L		●	●	●	●	●	1	0.5, 1, 2, 4-A	2	2		0, 1	20, 22
HS8207BA4KS/L	●		●	●	●	●	1	0.5, 1, 2, 4-A	2	2		0, 1	20, 22
HS8207BN3/L		●	●	●	●	●	1	1, 2, 4-N	2	2		0, 1	20, 22
HS8207BN3K/L	●		●	●	●	●	1	1, 2, 4-N	2	2		0, 1	20, 22
HS8207BA4/L		●	●	●	●	●	1	0.5, 1, 2, 4-A	2	1	1	0, 1	20, 22
HS8207BA4K/L	●		●	●	●	●	1	0.5, 1, 2, 4-A	2	1	1	0, 1	20, 22
HS8210BA4/L		●	●	●	●	●	1	0.5, 1, 2, 4-A	1	1		0, 1	16
HS8210BA4K/L	●		●	●	●	●	1	0.5, 1, 2, 4-A	1	1		0, 1	16